

User Manual

STL-7010 Safety Temperature Limiter

Benutzerhandbuch

STL-7010 Safety Temperature Limiter

Operation, maintenance, safety, and troubleshooting

Enthält auch deutsche Inhalte / Includes German content

Document ID	SensePro-STL-7010-UM-001	Document type	User Manual
Applies to	Model STL-7010	Language	Multilingual
Version	v1.0	Release date	2026-02-11
Owner	Technical Publications	Brand	SensePro

Confidentiality: Public demo content

English

1. Product overview

Safety limiter to protect boilers against over-temperature incidents.

Intended use: Safe operation within specified limits and in accordance with local regulations and site procedures.

2. Safety information

Only trained personnel may install or service the product. Isolate energy sources before maintenance. Use appropriate PPE.

3. Operation

Follow site procedures. Perform functional checks after installation and before returning to service.

4. Maintenance

Recommended interval: every 6 months or 2,000 operating hours. Inspect for damage, leaks, and corrosion.

5. Troubleshooting

Symptom	Possible cause	Remedy
Unexpected behavior	Incorrect setup or contamination	Verify installation, clean components, retest
Leakage	Seal wear or loose fasteners	Replace seals, tighten fasteners to spec
No output / no flow	Blocked line or device not energized	Check isolation, verify supply and process conditions

6. Technical data

Parameter	Value
triptemp	110°C
resettype	Manual
sensortype	Capillary
housingmaterial	Plastic
Mounting	DIN rail

Deutsch

1. Produktuebersicht

Safety limiter to protect boilers against over-temperature incidents.

Bestimmungsgemaesse Verwendung: Sicherer Betrieb innerhalb der angegebenen Grenzen und
gemaess lokalen Vorschriften und Werksstandards.

2. Sicherheitshinweise

Montage und Service nur durch geschultes Personal. Energiequellen vor Wartung abschalten und
sichern. Geeignete PSA tragen.

3. Bedienung

Werksstandards beachten. Funktionspruefung nach Montage und vor Wiederinbetriebnahme
durchfuehren.

4. Wartung

Empfohlenes Intervall: alle 6 Monate oder 2.000 Betriebsstunden. Auf Beschaedigungen, Leckagen und
Korrosion pruefen.

5. Fehlerbehebung

Symptom	Moegliche Ursache	Abhilfe
Unerwartetes Verhalten	Falsche Montage oder Verschmutzung	Einbau pruefen, reinigen, erneut testen
Leckage	Dichtung verschlissen oder Schrauben lockern	Dichtung ersetzen, Schrauben nach Vorgabe anziehen
Kein Ausgang / kein Durchfluss	Leitung blockiert oder keine Versorgung	Absperrungen pruefen, Versorgung und Prozessbedingungen

6. Technische Daten

Parameter	Wert
triptemp	110°C
resettype	Manual
sensortype	Capillary
housingmaterial	Plastic
Montage	DIN rail

Support

E-Mail: support@sensepro.example Tel: +49 30 555 0100